

Welche Kamera passt in welche Tasche?

Canon	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
IXUS 95 IS	10	15	10	10	10	10	20	10
IXUS 100 IS	10	15	10	10	-	10	20	10
IXUS 110 IS	10	15	10	10	10	10	20	10
IXUS 120 IS	10	15	10	10	-	10	20	10
IXUS 200 IS	20	20	10	10	10	-	-	10
IXUS 870 IS	10	15	5	10	10	-	20	-
IXUS 970 IS	20	20	20	10	-	-	-	-
IXUS 980 IS	20	20	20	20	-	-	-	-
IXUS 990 IS	20	20	20	10	-	-	-	-
PowerShot A480	20	30	20	20	-	-	20	20
PowerShot A1100 IS	30	30	-	-	-	-	-	20
PowerShot A2000 IS	20	20	-	-	-	-	-	20
PowerShot A2100 IS	20	30	30	20	-	-	-	20
Powershot S90	20	20	10	20	10	10	20	10
PowerShot SX120 IS	60	50	30	-	-	-	-	30
PowerShot SX200 IS	20	30	30	20	-	-	-	30
Powershot G10	60	-	35	-	-	-	-	-
Powershot G11	60	-	35	-	-	-	-	-
Casio	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
EXILIM EX-FC100	20	20	10	20	20	-	20	20
EXILIM EX-FS10	10	15	5	10	10	-	20	20
EXILIM EX-S10	10	20	10	10	10	10	20	10
EXILIM EX-Z9	20	15	5	10	10	-	20	10
EXILIM EX-Z77	20	15	5	10	10	-	20	10
EXILIM EX-Z80	10	10	5	10	10	10	20	10
EXILIM EX-Z85	10	10	5	10	10	10	20	10
EXILIM EX-S12	10	20	10	10	10	10	20	10
EXILIM EX-Z90	-	10	5	10	10	10	20	10
EXILIM EX-Z100	10	15	5	10	10	-	20	10
EXILIM EX-Z150/ Z250	20	20	5	10	10	10	20	10
EXILIM EX-Z200	10	15	5	10	10	-	-	10
EXILIM EX-Z270	20	15	5	10	10	10	20	10
EXILIM EX-Z280	20	20	5	10	10	10	20	10
EXILIM EX-Z400	20	15	5	20	10	-	20	10
EXILIM EX-Z450	20	20	20	20	10	10	20	10
Fujifilm	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
FinePix F70EXR	20			20	10	-	-	30
FinePix F200EXR	20	20	20	20	20	-	20	20
FinePix J10	20	20	5	10	10	-	-	-
FinePix J20	10	10	5	10	10	10	20	10
FinePix J30	-	15	5	10	10	10	-	10
FinePix J50	10	15	5	10	10	-	-	-
FinePix Z10fd/Z100fd	5	20	15	20	10	10	20	10
FinePix Z20fd	10	15	5	10	10	10	20	10
Finepix Z200fd	10	15	5	10	10	-	20	10
FinePix Z30		20	10	20	10	10		
FinePix Z33WP	10	10			10	10	-	10
FinePix Z35	-	15	10	10	10	10	-	10
FinePix Z300	10	10			10	10	-	10
GE	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
A735/A835	10	15	5	10	10	-	20	-
E1035/E1235	20	20	20	10	20	-	-	-
E1050	10	15	5	10	10	-	20	-
Kodak	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
EasyShare M340	20	20	10	10	10	-	20	10
EasyShare M763/M863	10	15	5	10	10	-	-	-
EasyShare M873/M883	10	20	10	10	10	10	20	10
EasyShare M1033	10	15	5	10	10	-	20	-
EasyShare M1063	10	15	5	10	10	-	-	-
EasyShare M1073 IS	10	15	5	10	10	-	20	-
Leica	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
C-Lux 3	20	20	5	10	10	-	-	-
D-Lux 3	20	30	20	20	-	-	-	10
D-Lux 4	20	30	20	20	-	-	-	-
Nikon	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
Coolpix P6000	-	-	35	-	-	-	-	-
S640	-	15	10	20	10	10	-	10
Coolpix S70	20	20	20	20	20	-	20	20
L20	20	30	20	20	20	-	-	20
Coolpix S570	-	15	5	20	10	10	-	10
Coolpix S200	10	15	5	10	10	10	20	10
Coolpix S210	10	15	5	10	10	10	20	10
Coolpix S220	10	15	10	10	10	10	20	10
Coolpix S230	10	15	5	10	10	10	20	10
Coolpix S550	10	15	10	10	10	10	10	10
Coolpix S600	10	15	5	10	10	-	-	-
Coolpix S610/ S610 c	10	15	5	10	10	-	20	-
Coolpix S700	10	15	5	10	10	-	-	-
Coolpix S1000pj	20	20	-	20	20	-	20	20

Welche Kamera passt in welche Tasche?

Olympus	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
FE-20	20	20	5	10	10	-	-	-
FE-25	20	20	20	20	-	-	-	-
FE-45	20	20	20	20	-	-	-	-
FE-46	20	30	30	20	-	-	-	30
FE-300	10	15	5	10	10	-	20	-
FE-320	10	15	5	10	10	10	20	10
FE-340	20	20	20	20	20	-	20	20
FE-3010	5+10	15	5	10	10	-	20	10
FE-4000	20	15	20	20	10	-	20	10
FE-5000/5010	20	20	20	10	-	-	-	-
FE-5020	20	30	20	20	-	-	20	20
Mju 830	20	20	20	10	10	-	-	-
Mju 840	20	20	10	10	10	-	-	-
Mju 850 SW	10	15	10	20	10	-	-	10
Mju 1010/ Mju1020	20	20	20	10	10	-	-	-
Mju 1030 SW	10	15	10	20	10	-	-	10
Mju 1050 SW	-	15	20	20	10	-	20	10
Mju Tough 6010	20	15	10	20	10	-	-	20
Mju 7010	20	30	30	20	-	-	-	30
Mju Tough 8000	20	15	10	20	10	-	-	-
Panasonic	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
Lumix DMC-FP8	20	20	20	20	10	10	20	10
Lumix DMC-FS3	20	20	10	10	10	-	-	10
Lumix DMC-FS5	20	20	10	10	10	-	-	10
Lumix DMC-FS6	20	20	10	10	10	-	-	-
Lumix DMC-FS7	20	20	10	10	10	-	-	-
Lumix DMC-FX33	20	20	10	10	10	-	-	10
Lumix DMC-FX35	20	20	10	10	10	-	-	10
Lumix DMC-FX37	20	20	10	10	10	-	-	10
Lumix DMC-FX60	-	15	10	20	10	10	20	10
Lumix DMC-FX500	20	15+20	20	20	20	-	20	10
Lumix DMC-FX550/FX580	20	20	5	10	10	-	-	-
Lumix DMC-LX3	60	60	30	20	-	-	-	-
Lumix DMC-TS1/FT1	20	20	10	20	10	-	-	-
Lumix DMC-TZ7/ZS3/TZ5/TZ6	30	30	30	-	-	-	-	20
Lumix DMC-ZX1	20	20	20	20	10	10	-	10
Lumix DMC FS62	-	15	10	10	10	-	-	-
Pentax	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
Optio A30	20	15	20	20	10	-	20	10
Optio A40	20	30	20	20	-	-	20	20
Optio E80	20	30	30	20	10	-	-	20
Optio E85	20	15	20	20	10	-	20	10
Optio P80	20	30	30	20	-	-	-	30
Optio W80	20	20	20	20	20	-	20	10
Optio WS80	20	30	20	20	-	-	20	20
Ricoh	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
GX 100 / GX200	30	30	20	20	20	-	-	20
G600	-	30	30	-	-	-	-	-
CX1	20	20	20	10	-	-	-	-
CX2	20	20	20	10	-	-	-	-
GXR	60	60	-	-	-	-	-	-
GX 200	30	30	20	20	-	-	-	20
GR Digital II	20	30	20	20	-	-	-	-
GR Digital III	20	30	20	20	-	-	-	-
Samsung	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
L310W	10	15	10	20	10	-	-	10
NV100 HD	20	20	10	10	10	-	20	10
NV9/TL9	20	20	10	10	10	-	-	10
ES55	10	15	5	10	10	-	-	-
ST500	20	20	10	20	10	-	20	10
ST550	20	20	10	20	10	-	20	10
ST1000	20	20	10	20	10	-	20	10
WB100	20	20	10	20	10	-	-	-
WB1000	20	20	10	20	10	-	-	-
Sony	Apex	Rezo	Ridge	Hipshot	Volta	Melbourne	Stockholm	Dublin
DSC-S750/S780	20	20	20	10	-	-	-	-
DSC-T2	10	10	5	10	10	-	-	10
TX7	-	-	-	-	-	-	-	10
DSC-T20	10	15	5	10	10	-	-	-
DSC-T300	10	15	5	10	10	-	20	-
DSC-T500	20	20	20	20	20	-	20	20
DSC-T70	10	10	-	-	10	10	-	10
DSC-TX1	-	15	-	20	10	10	-	10
DSC-WX1	20	20	10	10	10	10	20	10
DSC-W120/W130	10	15	5	10	10	-	-	-
DSC-W180	-	15	5	10	10	10	-	10
DSC-T90/T900	20	20	5	10	10	10	20	10
DSC-W150/W170	20	10	10	10	10	10	20	10
DSC-W210/W220	10	15	10	20	10	10	-	10
DSC-W230/W290	20	20	10	10	10	-	-	-
DSC-W275	20	20	20	20	20	-	-	10